




N° Object	Code	Description	Qty
129	601154	Timer	1
1014	ZS2026	Thermostat TY60 N.O. fixing B	1
1957	ZS3495	Washer 4.3 x 10 x 3	4
1996	ZS3171	Blocking plate hob-side Party	2
3717	ZS6026	Switch for induction encoder	5
4210	ZS5377	Energy regulator for induction 230 V EGO EU	5
4211	ZS5378	Induction 5 element EGO	1
4266	ZS6787	Encoders control board	1
4731	ZS7270	Rear support for induction 5 elements 90 cm	1
4751	ZS7386	Front support for induction 5 elements 90 cm	1
5536	GP0057	Assembly control panel front 6 zones induct electric oven OXF 90 Nero serygr.	1
5801	ZS8317	Display support	1
5661	ZC0108	Back splash for cooker 90 Oxf	1
5753	ZP0068	Thickness for profile	2
5783	ZS6817	Feet for electronic components EGO	3
5784	ZS6904	Cover for induction terminal board	1
5785	ZS6905	Bridge for induction terminal board	1
5870	GP0089	Assembly cooktop cooker 90 induction Prt/Drb	1
4320	ZS6725	Glass for 90 induction hob or cooker	1
5901	ZP0084	Commutator support 3 positions	2
5918	ZA0278	Aluminium adhesive badge "Lancellotti"	1
5922	ZA0329	Neutral knob CNR	6
6038	ZS8877	Support for electronic control induction element	1
6156	ZC0336	Frontal bar profile cooker 90 Nero Fumo	1



N° Object	Code	Description	Qty
94	481814	Commutator multif. for 90 built-in oven(no pizza)	1
455	ZS1075	Oven thermostat	1
538	ZS1204	Led transparent	2
539	ZS1205	Fluorescent green warning light	1
823	ZS1755	Fluorescent orange warning light	1
1588	ZS2889	Commutator oven functions 90 EGO	1
5572	ZA0247	Timer (red led) 1TP ERS watch hands	1
5573	ZA0248	Knob for timer matt Black	1
5764	ZP0083	Commutator support 2 positions	1
5771	ZP0132	Electrical display support OXF cook	1
5922	ZA0329	Neutral knob CNR	1
6010	ZA0338	Neutral knob CNR with "L"	1



N° Object	Code	Description	Qty
18	400006	Protection door	2
98	481913	Terminal block for oven 32 PA 233	1
392	ZS0903	Sintesi black foot H.15	4
1439	ZS2663	Cooling fan L=180 Plaset (AU)	1
1912	ZS2717	Lower guard for cooker 090 Party	1
1913	ZS2718	Muffle fan guard cooker 90 cm Prt / Drb	1
1944	ZS2719	Air conveyor for cooktop 090/100 Prb/Drb	1
3054	ZS5128	Ramp hole closing plate	1
5033	ZS7657	Door hinge for drawer door	2
5267	ZS8339	Upper guard for drawer 90	1
5268	ZS8340	Front support for muffle left side cooker 90ADG	1
5269	ZS8341	Front support for muffle right side cooker 90	1
5270	ZS8342	Rear support for muffle left/right side cooker 90	2
5271	ZS8343	Rear guard for cooker 90 ADG	1
5310	ZS8458	Counterdoor drawer cooker 90 ADG	1
5328	ZS8497	Drawer door cooker 090 ADG Sabbia	1
5528	GP0043	Assembly complete lower reinforcement left side	1
130	601156	Tapping screw M10 galvanized	2
5745	ZP0033	Plinth lateral left for cooker 90/100 high side OXF	1
5529	GP0044	Assembly complete lower reinforcement right side	1
130	601156	Tapping screw M10 galvanized	2
5746	ZP0034	Plinth lateral right for cooker 90/100 high side OXF	1
5655	ZC0100	Side external right/left higher Drb / Oxf Nero fumo	2
5731	ZC0191	Plinth for cooker 90 Oxf nero fumo	1
5917	ZA0277	Aluminium adhesive badge "Lancellotti" brass	1



N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
21	401638	Gasket oven 90	1	3260	ZS5175	Turnspit for oven 90 (4 forks + handle) - 04	1
82	481403	Thermoswitch 16 Ampere	1	3261	ZS5236	Turnspit motor reducer 50/60 Hz	1
84	481589	Grill heating element for oven 90	1	4115	ZS6631	Complete Lamp-holder for oven (max 25 W)	2
89	481727	Circular tangential oven 90 fan (AU) with fan and nut	1	4574	ZS6005	Fixing support for turnspit motor oven 60/90	1
128	601152	Spring fixing feeler for built-in oven	2				
720	451200	Chromed wire grid for oven 90 AU	2				
1209	414559	Lateral frame support for built-in oven	6				
1217	ZS2283	Oven lateral frame 30/60/90	2				
1225	ZS2312	Side muffle oven 30/60/90 enamelled 04	2				
1234	ZS2330	Enamelled muffle ceiling oven 90	1				
1235	ZS2332	Enamelled muffle bottom for oven 90	1				
1236	GR2334	Assembly rear muffle oven 90 enamelled 04	1				
1401	ZS2585	Tapping screw M5 aluminium	4				
1237	ZS2336	Enamelled muffle front side oven 90	1				
1249	ZS2366	Enamelled drip tray for oven 90	1				
1260	ZS2395	Hinge support 06	2				
1313	ZS2467	Grill heating element support for muffle oven 90 enamelled 04	1				
1314	ZS2468	Lower heating elem.support oven 90 04	1				
1315	ZS2469	Lower heating element tray oven 90 04	1				
1321	ZS2490	Trivet for oven 90 04	1				
1328	482325	Circular heating element 230V-2500W	1				
1333	ZS2289	Support for grillrod 60/90	1				
1347	ZS2486	Fan cover for oven 90 with turnspit hole 04 BLACK	1				
1349	ZS2499	Fixing support for turnspit motor oven 60/90	1				
1420	ZS2625	White glass wool for rear side 90 oven	1				
1421	ZS2626	White glass wool for 90 oven 04	1				
1467	ZS2604	Support for safety thermostat 04	1				
1839	ZS3082	Lower heating element for oven 90 (1400 W)	1				

6251

1221

4903

5333

6253

5921

5358

2943

6253


5358

4930

2944

6241

6240



N° Object	Code	Description	Qty
6251	GP0162	Assembly glued oven door 90 CNR SABBIA	1
4903	GR7666	Assembly door 30/60/90 right bar profile 15	1
4930	GR8097	Assembly door 30/60/90 left bar profile 15	1
5921	ZA0328	Door oven handle for oven 90 CNR	1
6253	ZP0216	Handle decorative plate	2
6240	ZP0217	Left hinge plate	1
6241	ZP0233	Right hinge plate	1
1221	ZS2307	Inner glass oven door 90	1
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
5333	ZS8519	Glued external oven door 90 sabbia	1
5358	ZS8596	Door hinge for oven 90	2

N° Object	Code	Description	Qty
123	541011	Spacer washer for built-in oven	8
131	BS0296	Adhesive tape 4959	600
132	ZS5148	Adhesive tape 16,5 m x 19h (3M)	40
725	601108	Anti-overturning device	0,3
1210	ZS5149	Adhesive tape 33 mt x 17h mm x th 0,6 mm (3M 4930)	200
1329	ZS5150	Adhesive tape 33 mt x 25h mm x Th 1.55 mm (3M)	10000
1586	ZS2770	Additional wiring generic L=75 cm Fem Fem	2
4760	ZS7453	Wiring diagram for cooker D9F-6I	1
5336	ZS8523	Instruction booklet cooker Adagio Lancellotti Multilanguage	1