







N° Object	Code	Description	Qty
268	ZS0511	Cast-iron grid 2 burners Sintesi	2
297	ZS0585	Upper right side support	1
298	ZS0586	Upper left side clamp	1
731	ZS0565	Cast-iron grid for wok	1
1014	ZS2026	Thermostat TY60 N.O. fixing B	2
1245	ZS2351	Complete upper left side squared	1
1246	ZS2353	Complete upper right side squared	1
1612	ZS3020	Support for connection top-base	2
3658	ZS5722	Cast-iron grid 1 burner Sintesi	1
4908	GR7839	Assembly cooktop cooker 120 double oven 4 burners/barbecue, Mega wok	1
5503	ZS6140	Display support	1
794	ZS1058	Vitroglass for fry-top/barbecue	1
1441	ZS2665	Support for fan timelag device	2




N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
19	400689	Gasket gas inlet	1	2543	601229	Spring fixing spark plug for triple ring P-4	1
36	414157	Rapid burner body G25 1,21	1	2562	506037	Screw M3x8 TC s.steel	6
37	414158	Auxiliary burner body G25 0,72	1	2563	ZS0907	Fixing nut for thermocouple	4
38	414159	Semi rapid burner body G25 0,94 (fish-kettle G20)	1	2575	505241	Screw M4	4
48	421323	Gas taps fixing bridle M60	4	3262	ZS5270	Burner spark plug Cast	3
93	481787	Ignition system 4 flames	1	3264	ZS5272	Thermocouple Cast L=750	1
265	ZS0504	Ramp fixing support	2	3552	ZS5843	Bezel for front left burner knob 58, bright chromed	1
322	ZS0636	Pipe ramp for front right auxiliary burner cooker 120 d.o. 6 burners	1	3553	ZS5844	Bezel for rear left burner knob 58, bright chromed	1
323	ZS0637	Pipe ramp for rear right rapid burner cooker 120 double oven 6 burners	1	3556	ZS5847	Bezel for front right burner knob 58, bright chromed	1
376	ZS0813	Micro catenary for 4 burners	1	3557	ZS5848	Bezel for rear right burner knob 58, bright chromed	1
378	ZS0819	Under knob collars fixing support	2	4711	ZS6772	Clamp support for main ramp	5
619	ZS1745	Ignition system 2 flames	1	5201	ZS8191	Triple ring burner spark plug sbf 4.5	1
620	ZS1746	Micro catenary for 2 burners	1	5204	ZS8194	Gasket for triple ring burner 4.5	1
1177	ZS2217	Gasket for auxiliary burner	1	5263	ZS8313	Plate central triple-crown burner 4.5	1
1178	ZS2218	Gasket for semi-rapid burner	1	5364	ZS8626	Auxiliary burner flame spreader	1
1179	ZS2219	Gasket for rapid burner	1	5365	ZS8628	Semi-rapid burner flame spreader	1
1567	ZS2923	Valved tap for auxiliary burner (bypass 0,27)	1	5366	ZS8630	Rapid burner flame spreader	1
1568	ZS2924	Valved tap for rapid/fish-kettle burner	1	5368	ZS8633	Plate triple-crown burner 4.5 Kw	1
1569	ZS2925	Valved tap for semi-rapid burner	1	5369	ZS8634	Spring fixing spark plug for triple ring P-4	1
1570	ZS2926	Valved tap for triple-ring burner	1	5370	ZS8635	Thermocouple SBF L=600 t.c.4.5	4
1571	ZS2927	Thermocouple SBF L=1100 (dis 0896)	2	5371	ZS8637	Triple ring burner body 4,5 Kw G20/20 0,72 0,95	1
1592	ZS2935	Rear ramp fixing support cooker 90/120	1	5372	ZS8638	Triple ring burner flame spreader 4.5	1
1632	ZS3021	Adapter female-male 1/2 BSP 04	1	5401	ZS8684	Plate rapid burner	1
1637	ZS3058	Pipe ramp for front left triple ring burner cooker 90 05	1	5402	ZS8685	Plate rapid burner	1
1638	ZS3059	Pipe ramp for rear left semi-rapid burner cooker 90 05	1	5403	ZS8686	Plate rapid burner	1
1801	ZS3376	Ramp 6 burners cooker 120 double oven 06	1				
2335	ZS4181	Thermocouple SBF L=600 t.c.4.5	1				
2445	ZS4294	Knob 58 for gas burners MTG	4				




N° Object	Code	Description	Qty
48	421323	Gas taps fixing bridle M60	2
378	ZS0819	Under knob collars fixing support	2
1567	ZS2923	Valved tap for auxiliary burner (bypass 0,27)	1
2335	ZS4181	Thermocouple SBF L=600 t.c.4.5	1
2445	ZS4294	Knob 58 for gas burners MTG	2
2543	601229	Spring fixing spark plug for triple ring P-4	1
2544	ZS4186	Fixing nut for thermocouple burner 4.5	2
2575	505241	Screw M4	2
3550	ZS5841	Bezel for central internal burner knob 58, bright chromed	1
3561	ZS5852	Bezel for central external burner knob 58, bright chromed	1
3741	ZS4836	Pipe ramp for t.c. 4.5 central burner cooker	1
3742	ZS4837	Pipe ramp for t.c. 4.5 external burner cooker	1
3791	ZS6109	Valved tap for triple-ring burner	1
5199	ZS8189	Triple ring burner body 4,5 Kw G20/20 0,72 0,95	1
5200	ZS8190	Triple ring burner flame spreader 4.5	1
5201	ZS8191	Triple ring burner spark plug sbf 4.5	1
5202	ZS8192	Plate triple-crown burner 4.5 Kw	1
5204	ZS8194	Gasket for triple ring burner 4.5	1
5206	ZS8197	Triple ring burner spark plug sbf 4.5	1
5207	ZS8198	Thermocouple SBF L=600 t.c.4.5	1
5208	ZS8199	Thermocouple SBF L=600 t.c.4.5	1
5209	ZS8200	Thermocouple SBF L=600 t.c.4.5	1
5263	ZS8313	Plate central triple-crown burner 4.5	1
5369	ZS8634	Spring fixing spark plug for triple ring P-4	1
5370	ZS8635	Thermocouple SBF L=600 t.c.4.5	4




N° Object	Code	Description	Qty
295	ZS0580	Fry-top cast-iron griddle	1
371	ZS0802	Commutator support 2 controls	1
379	ZS0820	Barbecue cast-iron griddle support	1
390	ZS0890	Spring for el. controls support	1
446	ZS1059	Heating element barbecue 1200/230 th.7	2
447	ZS1061	Spring for griddle heating el. support	2
538	ZS1204	Led transparent	2
539	ZS1205	Fluorescent green warning light	1
594	ZS1667	Protection frame for barbecue griddle	1
735	ZS1076	Energy regulator 230 V EGO EU	2
823	ZS1755	Fluorescent orange warning light	2
1192	ZS0553	Fry-top/barbecue stainless steel covering	1
2458	ZS4387	Knob 58 single heating element MTG	2
3554	ZS5845	Bezel for front central burner knob 58, bright chromed	1
3555	ZS5846	Bezel for rear central burner knob 58, bright chromed	1




N° Object	Code	Description	Qty
94	481814	Commutator multif. for 90 built-in oven(no pizza)	1
107	482120	Thermostat cooker 192	1
390	ZS0890	Spring for el. controls support	2
455	ZS1075	Thermostat for built-in oven	1
501	ZS1136	Commutator support	1
538	ZS1204	Led transparent	3
539	ZS1205	Fluorescent green warning light	1
708	ZS1916	Knob for timer steel-colour 988	6
740	ZS1747	Timer (blue led) 50 Hz	1
1895	ZS3652	Glass lcd 6 button no hole	1
2447	ZS4296	Knob 58 for oven temperature MTG	1
3217	ZS4568	Commutator oven functions 30 EGO	1
3551	ZS5842	Bezel for 30 oven functions knob 58, bright chromed	1
3559	ZS5850	Bezel for oven temperature knob 58, bright chrome	1
3560	ZS5851	Bezel for oven functions knob 58, bright chromed	1
4137	ZS6655	Commutator steam oven functions	1
5359	ZS8600	Knob 58 oven 30 functions MTG	1
5361	ZS8602	Knob 58 oven 60/90 functions MTG	1




N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
20	401520	Black cap for glass front panel	1	4615	ZS6967	Air conveyor for cooktop 030/120 double oven	1
98	481913	Terminal board for oven 32 PA 233	1	4616	ZS6968	Muffle fan guard cooker 120/120 double oven	1
123	541011	Spacer washer for built-in oven	4	4617	ZS6969	Drawer upper guard for cooker 120 double oven	1
300	GR0591	Assembly complete lower reinforcement right side	1	4618	ZS6970	Reinforcement for ceiling drawer cooker 120 double oven 04	1
130	601156	Tapping screw M10 galvanized	2				
301	GR0592	Assembly complete lower reinforcement left side	1				
130	601156	Tapping screw M10 galvanized	2				
392	ZS0903	Sintesi black foot H.15	4				
1166	ZS2211	Sintesi s.steel 988 foot H.35	4				
1243	ZS2347	Complete lower left side NF 04	1				
1244	ZS2349	Complete lower side panel DX Neff 04	1				
1316	ZS2474	Front central muffle support cooker 100/120 double oven	1				
1317	ZS2475	Front support for muffle R/L side 100/120 double/triple oven cooker	2				
1318	ZS2477	Rear support for muffle left/right side cooker 100 double/triple oven	1				
1364	ZS2524	Complete front profile for sides protection	2				
1414	ZS2601	Terminal board support	1				
1439	ZS2663	Cooling fan L=180 Plaset (AU)	2				
1549	ZS2905	Lower guard for cooker 120 double oven 04	1				
1550	ZS2906	Reinforcement for lower guard cooker 120 double oven 04	2				
1552	ZS2908	Reinforcement for ceiling drawer cooker 120 double oven 04	1				
1555	ZS2911	Rear support for muffle left side oven 90/120 double oven	1				
1556	ZS2912	Rear central support for muffle cooker 120 double oven	1				
1595	ZS2938	Ramp hole closing plate	1				
1713	ZS3264	Plinth for cooker 120	1				
1779	ZS3279	Rear guard for cooker 120 single / double oven 05	1				
4167	ZS6684	Reinforcement for lower guard oven	2				
4338	ZS6907	Air conveyor for cooktop 090/120 SF	1				
4505	ZS7051	Bracket condensate collection for 120 DC Steam	1				




N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
21	401638	Gasket oven 90	1	4115	ZS6631	Complete Lamp-holder for oven (max 25 W)	2
82	481403	Thermoswitch 16 Ampere	1	4123	ZS6653	Carafe graduate 0.5	1
84	481589	Grill heating element for oven 90	1	4124	ZS6654	Steam flexible pipe	1
89	481727	Circular tangential oven 90 fan (AU) with fan and nut	1	4134	ZS6615	Deep tray for cooking of vegetables 90 cm oven	1
128	601152	Spring fixing feeler for built-in oven	2	4148	ZS6380	Lower heating elem.support oven 90	1
714	401764	Handle M55/60 PH/WH U.K. for oven grill pan	2	4162	ZS6679	O-ring 3021 viton	1
1209	414559	Lateral frame support for built-in oven	6	4314	ZS6548	Complete Stainless Steel muffle ceiling oven 90	1
1260	ZS2395	Hinge support 06	2	4315	ZS6549	S.Steel muffle front side oven 90 complete	1
1328	482325	Circular heating element 230V-2500W	1	5216	ZS8229	Steam generator cover 90	1
1349	ZS2499	Fixing support for turnspit motor oven 60/90	1				
1420	ZS2625	White glass wool for rear side 90 oven	1				
1421	ZS2626	White glass wool for 90 oven 04	1				
1467	ZS2604	Support for safety thermostat 04	1				
1839	ZS3082	Lower heating element for oven 90 (1400 W)	1				
3260	ZS5175	Turnspit for oven 90 (4 forks + handle) - 04	1				
3261	ZS5236	Turnspit motor reducer 50/60 Hz	1				
3853	GR6226	Assembly rear muffle oven 90 S.steel TDL	1				
1401	ZS2585	Tapping screw M5 aluminium	4				
3919	ZS6002	Reinforce for fixing support for turnspit motor oven 60/90	1				
3939	ZS6341	S.steel Trivet for oven 90	1				
3941	ZS6343	S.steel wire grid for oven 90	2				
3948	ZS6379	Lower heating element tray oven 90	1				
4019	ZS6222	Side muffle oven 30/60/90 S.Steel TDL	2				
4021	ZS7595	Drip tray for oven 90 S.Steel TDL	1				
4023	ZS6245	Grill heating element support for muffle oven 90 S.Steel	1				
4026	ZS6248	Fan cover for oven 90 with turnspit hole S.STEEL	1				
4059	ZS6034	Oven lateral frame 30/60/90 S.Steel	2				
4085	ZS6543	Complete muffle bottom for oven 90 S.Steel Steam	1				




N° Object	Code	Description	Qty
3199	GR5862	Assembly glued oven door 90/120 double oven	1
4903	GR7666	Assembly door 30/60/90 right bar profile 15	1
4930	GR8097	Assembly door 30/60/90 left bar profile 15	1
1280	ZS2419	Spring for door glass assembling 04	2
1221	ZS2307	Inner glass oven door 90	1
1259	ZS2394	In-between glass oven door 90 04	1
1280	ZS2419	Spring for door glass assembling 04	4
1575	ZS2931	Spacer between glasses	4
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
3766	ZS6091	Door oven handle for oven 90 Bsh	1
5195	ZS8180	Door hinge for oven 90	2
5395	ZS8678	Glued external oven door 90/120 double oven	1



N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
6	071824	Turnspit hole cap	1				
82	481403	Thermoswitch 16 Ampere	1				
103	482072	Upper heating element cooker Ratio	1				
123	541011	Spacer washer for built-in oven	2				
128	601152	Spring fixing feeler for built-in oven	2				
188	ZS7653	Lower heating element for oven 30	1				
714	401764	Handle M55/60 PH/WH U.K. for oven grill pan	2				
1209	414559	Lateral frame support for built-in oven	6				
1217	ZS2283	Oven lateral frame 30/60/90	2				
1220	ZS2287	Chromed wire grid for oven 30	1				
1225	ZS2312	Side muffle oven 30/60/90 enamelled 04	2				
1226	ZS2314	Enamelled muffle ceiling oven 30	1				
1227	ZS2316	Enamelled muffle bottom for oven 30	1				
1228	ZS2318	Muffle rear side oven 30 enamelled 04	1				
1229	ZS2320	Enamelled muffle front side oven 30	1				
1247	ZS2362	Enamelled drip tray for oven 30	1				
1260	ZS2395	Hinge support 06	2				
1303	ZS2454	Lower heating elem.support oven 30 04	1				
1304	ZS2455	Lower heating element tray oven 30 04	1				
1319	ZS2488	Trivet for oven 30 04	1				
1324	ZS2494	Grill heating element support for muffle oven 30 enamelled 04	1				
1333	ZS2289	Support for grillrod 60/90	1				
1413	ZS2599	Gasket oven 30 04	1				
1422	ZS2627	White glass wool for rear side 30 oven 04	1				
1423	ZS2628	White glass wool for 30 oven 04	1				
1467	ZS2604	Support for safety thermostat 04	1				
4115	ZS6631	Compete Lamp-holder for oven (max 25 W)	1				
4574	ZS6005	Fixing support for turnspit motor oven 60/90	1				



N° Object	Code	Description	Qty
3196	GR5859	Assembly glued oven door 30	1
2937	GR4313	Assembly door 30/60/90 right bar profile 07	1
2938	GR4314	Assembly door 30/60/90 left bar profile 07	1
1224	ZS2311	Inner glass oven door 30	1
1256	ZS2390	In-between glass oven door 30 04	1
1276	ZS2413	Door hinge for oven 30	2
1280	ZS2419	Spring for door glass assembling 04	6
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
3764	ZS6089	Door oven handle for oven 30 BOSCH	1
5390	ZS8672	Glued external oven door 30 KL	1



N° Object	Code	Description	Qty
817	ZS0458	Drawer right regulation clip	1
818	ZS0459	Drawer left regulation clip	1
4062	ZS6372	Couple legobox rails partial opening push pull	1
4164	ZS6681	Drawer lateral side for cooker S.Steel	2
4419	ZS6823	Drawer door cooker 120 DC S.Steel	1
4420	ZS6824	Counterdoor drawer cooker 100 double oven	1
4421	ZS6825	Bottom drawer for cooker 120 DC S.Steel	1
4422	ZS6826	Drawer rear side for cooker 120 double oven S.Steel	1
5265	ZS8327	"Lancellotti" plate	1

N° Object	Code	Description	Qty
132	ZS5148	Adhesive tape 16,5 m x 19h (3M)	160
725	601108	Anti-overturning device	0,3
1210	ZS5149	Adhesive tape 33 mt x 17h mm x th 0,6 mm (3M 4930)	20
1586	ZS2770	Additional wiring generic L=60 cm Fem Fem	2
2225	ZS3976	Gasket aerostop	1
2392	ZS3990	Rear panel drawer BBQ	1
3257	ZS5157	Gasket aerostop	2
3740	ZS3397	Additional wiring ground L=10 Party cm Fem Fem	2
4657	ZS7303	Wiring diagram for cooker S12FF-6B and S12FF-6T	1
5047	ZS7807	Fan cover for oven 90 with turnspit hole S.STEEL	1
5212	ZS8219	Aluminium adhesive badge "CombiSteam"	1
5337	ZS8524	Instruction booklet cooker Maestro MULTILANGUAGE	1
5431	ZS8787	Instruction booklet Combi-Steam oven	1
5449	ZS8826	Triple ring 3.3 burner nozzle G25/20 1.37 F2	1
5450	ZS8827	Triple ring 3.3 burner nozzle G25/20 1.37 F2	1
5451	ZS8828	Triple ring 3.3 burner nozzle G25/20 1.37 F2	1